

DF22 Dispenser

DAILY SET-UP

1. Verify that the Power Switch is in the OFF position.
2. Plug the Power Cord into a wall outlet.
3. Install the Hopper, Drum, and Fry Diverter.
4. Fill the Hopper with Frozen Fries and install the Hopper Cover.
5. Turn on the Dispenser and Select a Load Size .
6. To fill a Fry Basket, place a basket under the Accumulator Doors and Press the Dispense Button.

DAILY CLOSING

1. Turn the Power Switch to the OFF position.
2. Remove all Fry Baskets from the Dispenser.
3. Remove the Hopper Lid by lifting it UP and BACK to unhook the tab.
4. Hang the Hopper Lid on the front of the Hopper, by hooking the tab on the lip of the Hopper.
5. Discard any Fries remaining in the Hopper at closing.
6. Check that the Accumulator Doors are empty of Fries.
 - Tip: *Turn the Dispenser Power ON*
 - *Press and hold the calibration button until the Accumulator Doors open*
 - *Turn the Dispenser Off, the Accumulator Doors will close when the Dispenser is turned back On.*
7. Disconnect the Power Cord from the electrical outlet.
8. Remove the Fry Diverter by grasping it and pulling it UP.
9. Slide the Locking Pins outward to release the Hopper.
10. Remove the Hopper, Lid and Drum.
11. Remove the Basket Shelf and Drip Tray.
12. Take the components removed from the Fry Dispenser to the back sink. Wash them in a hot solution of **McD APC (HCS)** and water, rinse in clear water, sanitize and allow to air dry.
13. Wipe down the Fry Dispenser with a hot solution of **McD APC (HCS)** and water. Repeat wipe-down with clear water, then with sanitizer and allow to air dry.
 - NOTE:** Do NOT spray down the Dispenser. It is not sealed, and contamination may get into sensitive components.
14. Move the Dispenser out from the wall, so that you can clean behind and underneath it.
 - NOTE:** DO NOT move the Dispenser to the back sink for cleaning. This will cause unnecessary wear on the Dispenser.
15. Dry all parts and reassemble the Fry Dispenser.
16. Roll the Dispenser back into place.