



GDF14

DAILY SET UP

1. Make sure the Power Switch is OFF.
2. Assemble the Dispenser.
3. Plug the Power Cord into a wall outlet.
4. Turn ON the Dispenser. Depending on the previous operation, the Dispenser will be in either Normal Operating mode or Automatic Operation mode.
5. Fill a Fryer Basket by placing it under the Accumulator Doors and pressing the Dispense button. When in Auto mode the Dispenser will automatically fill the basket when it is placed under the Accumulator Doors and is detected by the Basket Sensor. The Red Indicator Light on the Control Panel turns OFF (does not illuminate) when it detects a basket in proper position. The Light illuminates when the Dispenser delivers a basket load.

DAILY CLOSING

1. Remove all Fryer Baskets from the Dispenser.
2. If the Hopper and/or Accumulator Doors are not empty, select the Empty Hopper mode using the Scroll Down  button on the Control Panel. Press the Dispense  button to empty remaining product into the waiting basket.
3. Turn the Power Switch to the OFF position.
4. Disconnect Power Cord from the electrical outlet.
5. Remove the Hopper, Lid and Drum assembly.
6. Remove the Accumulator Tray, Basket Rack and Crumb Tray.
7. Take removable components from the Dispenser to the washing area. Wash them in a hot solution of sanitizing solution and water, rinse in clear water and allow to air dry (wash /rinse/sanitize).

WARNING: The Drum, Hopper, Hopper Lid, Accumulator Tray, Crumb Tray and Fry Diverter are NOT dishwasher safe.

8. Wipe down the Dispenser with a hot solution of sanitizing solution and water. Repeat wipe-down with clear water and allow to air dry.

WARNING: Do NOT spray down the Dispenser with water. The Dispenser does not provide an airtight seal. Contaminants and moisture may get into sensitive components.

9. Move the Dispenser out from the wall to clean behind and underneath it.

WARNING: Do NOT move the Dispenser to the back sink for cleaning, this will cause unnecessary wear on the Dispenser.

10. Dry all parts and reassemble the Dispenser.
11. Roll the Dispenser back into place.