

Bulletin #7

Automated Equipment, LLC
 5140 Moundview Drive
 Red Wing, Minnesota 55066
 Phone: 1-800-248-2724
 1-651-385-2273
 Fax: 1-651-385-2172
 http://www.autoequillc.com




Cablaggio interruttori per i distributori AFD-200, AFD-280, AFD-280U, AFD-280E e GDF28.

Assembly and disassembly instructions


Mounting adaptor

Assembly



Embossed word 'TOP' on back of operator


Disassembly




Note: Gently push locking lever and turn as shown over locking 'rib'

Contact blocks and full voltage light units

Assembly




Disassembly



Lamp replacement

Rear of panel


Disconnect power.
 Remove light unit as shown opposite.
 Remove bayonet type lamp (push and turn counter-clockwise).
 Insert new lamp.
 Reassemble light unit to operator as shown opposite.





Recommended tightening torque for wiring terminal screws is 0.8 Nm (7 lb-in).

Bulletin #7

Automated Equipment, LLC
 5140 Moundview Drive
 Red Wing, Minnesota 55066
 Phone: 1-800-248-2724
 1-651-385-2273
 Fax: 1-651-385-2172
<http://www.autoequillc.com>




Tasto Restart N/P 215606
 L'operatore del tasto Restart è disponibile separatamente. N/P 290771
 Lampadina di ricambio N/P 216489






Bulletin #7

Automated Equipment, LLC
 5140 Moundview Drive
 Red Wing, Minnesota 55066
 Phone: 1-800-248-2724
 1-651-385-2273
 Fax: 1-651-385-2172
<http://www.autoequi LLC.com>



Selettore N/P 215607



Bulletin #7

Automated Equipment, LLC
 5140 Moundview Drive
 Red Wing, Minnesota 55066
 Phone: 1-800-248-2724
 1-651-385-2273
 Fax: 1-651-385-2172
<http://www.autoequiplc.com>



Interr. Alimentazione

