

Bulletin #7

Automated Equipment, LLC
 5140 Moundview Drive
 Red Wing, Minnesota 55066
 Phone: 1-800-248-2724
 1-651-385-2273
 Fax: 1-651-385-2172
 http://www.autoequipllc.com




CONEXIONES DE LA LLAVE PARA DISPENSADORES AFD-200, AFD-280, AFD-280U, AFD-280E Y GDF28.

Assembly and disassembly instructions


Mounting adaptor

Assembly



Embossed word 'TOP' on back of operator


Disassembly




Note: Gently push locking lever and turn as shown over locking 'rib'

Contact blocks and full voltage light units

Assembly




Disassembly



Lamp replacement


Rear of panel

Disconnect power.
 Remove light unit as shown opposite.
 Remove bayonet type lamp (push and turn counter-clockwise).
 Insert new lamp.
 Reassemble light unit to operator as shown opposite.





Bulletin #7

Automated Equipment, LLC
 5140 Moundview Drive
 Red Wing, Minnesota 55066
 Phone: 1-800-248-2724
 1-651-385-2273
 Fax: 1-651-385-2172
<http://www.autoequipllc.com>




LA LLAVE OPERADORA DE REARRANQUE ESTÁ DISPONIBLE POR SEPARADO. P/N 290771
 LÁMPARA DE REEMPLAZO P/N 216489






Bulletin #7

Automated Equipment, LLC
 5140 Moundview Drive
 Red Wing, Minnesota 55066
 Phone: 1-800-248-2724
 1-651-385-2273
 Fax: 1-651-385-2172
<http://www.autoequipllc.com>



Llave Selector P/N 215607



Bulletin #7

Automated Equipment, LLC
 5140 Moundview Drive
 Red Wing, Minnesota 55066
 Phone: 1-800-248-2724
 1-651-385-2273
 Fax: 1-651-385-2172
<http://www.autoequipllc.com>



Llave de Poder

